I'm not robot	
	reCAPTCHA

Continue



```
"//I\I\, L ~\IIR And FRIG And R.A. TORI-FI\I\I'i'. A.NU. A.L CARE • OPERATION • RECIPES the team that is on your side ... all the way! When you bought it, you recognized that Sears-branded devices, like your new Coldspor, represent better value for your money. They also represent something else that is imposing
on you. . . a way to do business that helps strengthen America's economy. In short, Sears does a lot of things when dealing with manufacturers who make this company's branded merchandise. First, of course, comes the effort to bring more customers to their money. To this end, Sears buyers and suppliers work to improve engineering
and manufacturing manufacturing processes and methods. Our buyers know what Sears customers want. They provide, through Sears research and development laboratories, that technical aid manufacturers may not even be able to afford. As a result, vendors can plan production more efficiently and reduce costs. And a lot of that
savings are passed on to you, the customer. This type of agreement helps se;,rs suppliers to grow and prosper. Thus, more jobs are created for people in the communities where these manufacturers are located. Sometimes this policy even leads to ro to set up a factory in an area that has a little industry. Then the factory payroll becomes
an additional income spent largely at home to benefit local businesses. That's the buying policy that rhar brings fine equipment with Rhe Coldspor, Kenmore or Homart name. Such are the ideas and efforts that bring excellent values in a number of other Sears brand name items. These are some of the reasons why you had a wide choice
from which ro select rhe Coldspot best suited your needs. That's why you can expect it to serve you well for the years to come. Many people have a considerable stake in ensuring that you will be satisfied with buying a Sears branded product. SEARS, ROEBUCK AND COMPANY PAGE Cleaning - - - - - - Cold Control Adjustments 22-23
16 Defrosting Cycle Defrost Models - - - - 20 Frosrless Cold Guard Models - - - 20 Frosrless Refrigerator-Freezer SI3GIM Frostless Refrigerator-Freezer SI5GIM Frostless Refrigerator-Freezer SI3GIM Frostless Refrigerator-Freezer SI4G - Frostless Refrigerator-Freezer SI5GIM Frostless Refrigerator-Fr
- Frostless Refrigerator-Freezer S 14E - Frosrless Refrigerator-Freezer SI2E - Refrigerator-Freezer SI2D - Refrigerator-Freezer SI2D - Refrigerator-Freezer SI2D - Refrigerator SI2A 2-3 2-3 4-5 4-5 6 7 8 9 10 Refrigerator SI2A 2-3 2-3 4-5 4-5 6 7 8 9 10 Refrigerator-Freezer SI2E - Refrigerator-Freezer SI2D - Refrigerator-Freezer SI2D - Refrigerator-Freezer SI2D - Refrigerator SI2A 2-3 2-3 4-5 4-5 6 7 8 9 10 Refrigerator-Freezer SI2D - Refrigerator
- - - 12-13 What You Should Know Know He - 13 Packaging Materials - - - - Revenue Service 18-19 26-29 - 32 Service Facts (Any Doubts?) - - 30-31 Your new Coldspor has a magnetic door that remains firmly closed, but can be opened from the inside by a slight push. DO NOT LET YOUR REFRIGERATOR NOT USED TO BECOME A
DEATH TRAP I If you are not using your old refrigerator - please remember to remove the door. If you leave the door open, it can easily become a death trap for some child, perhaps your own. In some cities, local ordinances impose heavy penalties for not removing such doors. FEAT U RES m Coldspot Cooler-freezer FEATURES: S16G
S15GIM 1 FLUORESCENT LIGHTING: Bright lighting as the day of the whole section of fresh food. 2 COLD GUARD WITHOUT ICE: Forced cooling of air that provides continuous flow of cold air through the fresh food section. You never have to thaw. 3 SPACEMASTER SHELVES: Six space-saving shelves that allow the use of every
inch of fresh food storage area. See pages 12 and 13. 4 EGG BASKET: Portable, can be stored on any shelf. 5 COLD CONTROLS: Separate controls for refrigerator and freezer. See page 16. 6 MEAT KEEPER: Porcelain pan attached to the special spacemaster shelf. To store fresh meats, bacon, cold cuts, etc. Locate in front of the
meat cooler grille (6A, see page 4) for a cooler storage temperature. 7 SLIDE-OUT BOTTLE TRAY: Hold gallon-sized containers or store 12 cartons of milk in a room. 8 CRISPER COVER SHELF: Plastic, removable. 9 CRISPERS TWIN SLIDE-OUT: Keep vegetables and fruits crispy and fresh. 10 STATIONARY SHELVES: One is
lowered to additional depth to contain half-gallon milk cartons. 11 ADJUSTABLE DOOR SHELVES: Adjust without unloading. The bottom shelf accommodates tall bottles. 12 MAGNETIC KNUckle: Silent door closing with positive seal. 13 BUTTER AND CHEESE COMPARTMENTS: Soft temperature control in the butter compartment. 14
DOOR PEDAL: Lightly step on the pedal and the refrigerator door opens automatically. 15 CLEAN BACK STYLE: The refrigerator can be placed directly against the wall. 16 STOP PORT: Adjustable to stop at 85 or 110 degrees. FREEZER FEATURES: S16G, S15GIM 17 FREEZER TRUE FROSTLESS: Never need thawing. 18
ADJUSTABLE FREEZER SHELF: Adjustment of two positions. 19 FREEZER BASKET: Spacious elevator. The outlet basket provides easy access to frozen food. 20 AUTOMATIC ICE MAKER (SI5-GIM only): Automatically stores, stores and replenishes the supply of ice circles in the storage basket. Full instructions are on-S16G
(Catalogue Series 1660) deluded in the small booklet attached to the Ice Maker. 21 ICE AUTO CUBE (S16G only, see inlet): Ice container with two ejector trays and lid. The container guide rails . . . Push handle down to eject cubes. 22 FREEZER DOOR
SHELVES: Two deep shelves for storing frozen food packaging. S15GIM S15GIM Series #1503) NOTE/ Your Coldspot may contain a different combination of features, depending on the model you choose or due to periodic product improvement. S16G S15GIM PRESENTS M Coldspot Frostless Refrigerator-Freezer FRIDGE FEATURES:
S14G, S13GIM 1 FLUORESCENT LIGHTING: Bright lighting as the day of the whole section of fresh food. 2 COLD GUARD WITHOUT ICE: Forced cooling of air that provides continuous flow of cold air through the fresh food section. You never have to thaw. 3 SPACEMASTER SHELVES: Five space-saving shelves that allow the use of
every inch of fresh food storage area. See pages 12 and 13. 4 EGG BASKET: Portable, can be stored on any shelf. 5 COLD CONTROLS: Separate controls for refrigerator and freezer. See page 16. 6 MEAT KEEPER: Porcelain pan attached to the special spacemaster shelf. To store fresh meats, bacon, cold cuts, etc. Locate in front of
the meat cooler grill (6A) for colder storage temperature. 7 SCROLL BOTTLE TRAY: Hold gallon-sized containers or store 12 cartons of milk in a room. 8 CRISPER COVER SHELF: Plastic, removable. 9 CRISPERS TWIN SLIDE-OUT: Keep vegetables and fruits crispy and fresh. 10 STATIONARY DOOR SHELF: Lowered to additional
depth to contain half-gallon milk cartons, 11 JUS AD TABLE DOOR SHELVES: Adjust without unloading. 12 MAGNETIC KNUckle: Silent door closing with positive seal. 13 BUTTER AND CHEESE COMPARTMENTS: Soft temperature control in the butter compartment. 14 DOOR PEDAL: Lightly step on the pedal and the refrigerator door
opens automatically. 15 CLEAN BACK STYLE: The refrigerator can be placed directly against the wall. 16 STOP PORT: Adjustment of two positions. 19
FREEZER BASKET: Spacious lifting basket provides easy access to frozen food. 20 AUTOMATIC ICE MAKER (SI3-GIM only): Automatically stores, stores and replenishes the supply of ice circles in the storage basket. The complete instructions are on- S14G (Catalog Series No. 1460) deluded in the small booklet attached to the lee
Maker. 21 ICE AUTO CUBE (S14G only, see inlet): lee container with two aluminum ejector trays and lid. The container stores cubes until it is needed. Turn the tray upside down... set tray on container guide rails ... Push handle down to eject cubes. 22 FREEZER DOOR SHELVES: Two deep shelves for storing frozen food packaging.
S13GIM (Catalog Series No. 1303) NOTE I Your Coldspot contain a different combination of features, depending on the model you choose or because of periodic product improvement. S14G S13GIM PRESENTS 'In Coldspot Frostless FridgeFreezer S14F REFRIGERATOR 1 MODERN LIGHTING: Soft lighting throughout the
refrigerator. 2 COLD GUARD WITHOUT ICE: Forced cooling of air that provides controlled continuous flow of cold air through fresh food You never have to thaw. 3 COLD CONTROLS: Separate controls for refrigerator and freezer. See page 16. 4 FULL WIDTH SHELVES: Anodized aluminum. One is sliding, the other adjustable. 5
EGG BASKET: Portable, can be stored on any shelf. 6 LIFT-OUT HALF SHELF: Provides maximum shelf flexibility. FEATURES: S14F 7 CRISPER COVER SHELF: Plastic, removable. 8 CRISPERS TWIN SLIDE-OUT: Keep vegetables and fruits crispand fresh. 9 STATIONARY SHELVES: One is lowered to additional depth to contain
half-gallon milk cartons. 10 MAGNETIC KNUckle: Silent door closing with positive seal. 11 BUTTER AND CHEESE COMPARTMENTS: Convenient storage for butter and cheese. 12 CLEAN BACK STYLE: The refrigerator can be placed directly against the wall. FREEZER F EAT U R E S: S 1 4 F 13 FROSTLESS TRUE FREEZER:
Never need to defrost. 14 ADJUSTABLE FREEZER SHELF: Adjustment of two positions. 15 FREEZER BASKET: Spacious lifting basket provides easy access to frozen food. 16 ICE with two ejector trays and lid. The container stores cubes until it is needed. Turn the tray upside down... set tray on con-tainer guide rails... Push handle
down to eject cubes. 17 FREEZER DOOR SHELVES: Two deep shelves for storing frozen food packaging. S14F (Catalog Series #1450) Your Coldspot may contain a different combination of features, depending on the model you choose or because of the periodic product improvement. REFRIGERATOR 1 MODERN LIGHTING: Soft
lighting throughout the refrigerator. 2 COLD GUARD WITHOUT ICE: Forced cooling of air that provides continuous flow of cold air through the fresh food section. You never have to thaw. 3 COLD CONTROLS: Separate controls for refrigerator and freezer. See page 16. 4 FULL WIDTH SHELVES: Anodized aluminum. One is sliding, the
other adjustable. 5 LIFT-OUT HALF SHELF: Provides maximum shelf flexibility. FEATURES: S14E 6 CRISPER COVER SHELF: Plastic, removable. 7 CRISPERS TWIN SLIDE-OUT: Keep vegetables and fruits crispand fresh. 8 SHELF DE RACK OF EGGS: Stores 12 eggs. 9 BUTTER COMPARTMENT: Convenient storage for butter. 10
STATIONARY SHELVES: One is lowered to additional depth to contain half-gallon milk cartons. 11 MAGNETIC KNUckle: Silent door closing with positive seal. 12 CLEAN BACK STYLE: The refrigerator can be placed directly against the wall. FREEZER F EAT U R E S: S14E 13 FROSTLESS TRUE FREEZER: Never need to defrost. See
page 20. 14 ICE CUBE TRAYS WITH LID: Two trays of anodized aluminum shucker type ice cubes. Frozen food packaging solves food packaging. S14E (Catalog Series No. 1440) tn Coldspot Frostless FridgeFreezer St4E 11 1.,. I'FEATURES tn Coldspot Frostless
FridgeFreezer S12E REFRIGERATOR 1 MODERN LIGHTING: Soft lighting throughout the refrigerator and freezer. See page
1>6. 4 FULL WIDTH SHELVES: Anodized aluminum. One is adjustable. 5 CRISPER COVER SHELF: Plastic, removable. FEATURES: ST2E 6 TWIN SLIDE-OUT CRISPERS: Keep vegetables and fruits crisp and fresh. 7 SHELF DE RACK OF EGGS: Stores 12 eggs. 8 BUTTER COMPARTMENT: Convenient storage for butter. 9
STATIONARY SHELVES: One is lowered to additional depth to contain half-gallon milk cartons. 10 MAGNETIC GASKET: Silent door closing with positive seal. FREEZER F EAT U R E S: S t 2 E 11 FREEZER TRUE FROSTLESS: Never need to defrost. See page 20. 12 ICE CUBE TRAYS: Two trays of anodized aluminum ice cubes. 13
FREEZER DOOR SHELF: Deep shelf for storing frozen food packaging. S12E (Catalog Series No. 1240) NO E/Your Coldspot may contain a different combination of features, depending on the model you choose or because of the periodic product improvement. REFRIGERATOR 1 DEFROST CYCLE: Defrostautomatically. 2 COLD
CONTROL: Easily adjusted to get the temperature you want. See page 16. 3 FULL WIDTH SHELVES: Rust resistant. One is adjustable. 4 MODERN LIGHTING: Soft lighting throughout the refrigerator. 5 CRISPER COVER SHELF: Glass, removable. FEATURES: S12 D 6 FULL-WIDTH SLIDE-OUT CRISPER: Keeps vegetables and fruits
crisp and fresh. 7 SHELF DE RACK OF EGGS: Stores 12 eggs. 8 BUTTER COMPARTMENT: Convenient storage for butter. 9 STATIONARY SHELVES: One is lowered to additional depth to contain half-gallon milk cartons. 10 MAGNETIC GASKET: Silent door closing with positive seal. F R E E Z E R F EAT U R E S: S 1 2 D 11 TRUE
FREEZER: A separate true freezer located above. See page 20. 12 ICE CUBE TRAYS: Two trays of anodized aluminum ice cubes; one is shucker type, a plastic grid. 13 FREEZER DOOR SHELF: Deep shelf for storing frozen food packaging. 5120 (Catalog Series No. 1230) tn Coldspot RefrigeratorFreezer S12D FEATURES in Coldspot
Refrigerator S12A REFRIGERATOR 1 FREEZER CHEST: Plenty of storage space for frozen food . . It rw_o a trays of aluminum ice cubes w1th plasuc grids. 2 CHILLER TRAY: For storing meat or other plain food packaging. Remove the contents when using the tray to collect thawed water during thawing periods. 3 COLD CONTROL:
Easily adjusted to get the temperature you want. See page 16. 4 LIGHTING: Fresh food section. FEATURES: SHELVES S12A 5 LIFT-OUT: Resistant To 6 CRISPER FULL WIDTH SLIDE-OUT: Keeps vegetables and fruits crisp and fresh. 8 DOOR SHELVES: One is lowered to additional
depth to contain half-gallon milk cartons. 9 MAGNETIC GASKET: Silent door closing with positive seal. S 12A (Catalog Series No. 1 205) REFRIGERATOR 1 FREEZER CHEST: Plenty of storage space for frozen food. It has two trays of aluminum ice cubes with plastic grilles. 2 CHILLER To store meat or other plain food packaging.
Remove the contents when using the tray to collect thawed water during thawing periods, 3 COLD CONTROL; Easily adjusted to get the temperature vou want, See page 16, 4 LIGHTING; Fresh food section, 5 LIFTING SHELVES; Rust resistant, FEATURES; S 1 OA 6 CRISPER COVER SHELF; Glass, removable, 7 CRISPER FULL
WIDTH SLIDE-OUT: Keeps vegetables and fruits crisp and fresh. 8 BUTTER COMPARTMENT: Convenient storage for butter. 9 SHELF DE RACK OF EGGS: Stores 16 eggs. 10 DOOR SHELVES: One is lowered to additional depth to contain half-gallon milk cartons. 11 MAGNETIC KNUckle: Silent door closing with positive seal. S10A
(Catalog Series No. 1105) NOTE/ Your Coldspot may contain a different combination of features, depending on the model you choose or due to periodic product improvement. i IIIIIIIIIIW tn Coldspot Refrigerator S10A 11 FROST LESS COLD GUARD Bottom Freezer COLD GUARD COLD GUARD TOP FREEZER CYCLE DEFROST M 0
DE HOW IT WORKS Cold Guard R N Frostless Cold Guard is more than just defrosting autOmatic. Cold air is boosted to both fresh food and stOrage areas. Cooled air
passes through a hidden distribution system similar to a forced home heating system. The vents are located on the rear wall tO provide inlet and outlet openings for air circulation. Cold air circulation continues until the proper temperatures have been reached. Each storage area compartment is individually regulated by its own cold control
to provide bespoke temperatures. Air circulation standards have been designed to meet the needs of each specific type of refrigeratOr. Models with freezers at the freezer at the top have another. The result is the same... Cold Guard without ice.
SpaceMASTER Archived Space Stunning provides full shelf arrangement flexibility. The shelves are easily adjusted according to your varied requirements. Look at the illustrations. You'll see that combinations of large and small items do not interrupt the storage arrangement. R E F R I G The True Freezer in these models provides an
efficient and modern method for preserving frozen foods with fully automatic defrosting. Frost Cycle The fresh food storage area has a refrigerated plate located on the inner wall. The is at a temperature well below zero while the unit is operating. Moisture accumulates in the plate and forms frost. When the unit is not working, the
temperature of the refrigerated plate rises above the freezing point, and the frost melts. Thawed water flows through hidden tubes view, and finally goes into the pot of frostwater from which the water evaporates. The Real Freezer should be thawed periodically. See page 20. What you should know about it The appliance in your
new refrigerator may work more than that of your old refrigeration methods give more uniform temperatures than older methods. • The capabilities of both fresh food and frozen food storage areas are much greater. Although the unit can
operate longer, the operating cost per cubic foot will be roughly the same as the older model. Modern engineering research and methods have made this possible. The runtime is unnecessarily increased (except in models without ice), if the frost buildup exceeds ~ inch on refrigerated surfaces. The new modern and fan-like condensers
(located behind the front grille) need to be cleaned occasionally (at least every few months) because: • If the condenser may cause the unit to collapse. {- .... \) /' ' ...... ,, ... -\\\ ... I'm in? ~~ I ~ yv ( ..... .\... ... Be sure to inspect
your new Product has been inspected and found in perfect condition before it is shipped from the carriage. If you find shipping damage or parts are missing, make a claim at once: 1 If purchased at a Sears or Simp-sons-
Sears store, and delivery was done by truck, call the Customer Service Desk at the store where you made the purchase. 2 If purchased from a Sears Or Simpsons-Sears Or Mail Order House Sales Office, do not destroy box . . . contact transport company. When the claim agent recognizes the damage, make sure he signs the boarding
pan located at the bottom. • From the pan, trays and shelves. 2 Locate all components correctly, refer to the appropriate model in the manual 3 Check the owner's pipe. IJ~ -~~ ~ 4 Determine location • Locate in dry area and away from any heat or direct
sunlight. • The floor support should be strong enough to support the fully charged refrigerator. • Locate near the wall exit. A. The voltage should be 110-120, 50/60 AC current when at full load at the moment of departure, with all other appliances or lights on. If the cooler works in a 50-cycle current, frost removal frost will occur less
frequently. B. Do not overload the refrigerator wall outlet with other appliances, c. The outlet must not be controlled by switches or pull currents and as short as possible. INSTALLATION • Models with the condenser mounted on the
back of the cabinet should be 3 inches slack on each side and 6 inches off at the top. Models without back-mounted condenser can be positioned against the wall. 5 The enclosure must be level • Four adjustable screw leveling legs are supplied with the refrigerator - two are factory installed in the front corners; two packed in a small
envelope inside the refrigerator (except SIOA models, SI2A). • Fix two packed levelers in the rear corners of the refrigerator. • Adjust the level legs so that the refrigerator cabinet everywhere. Check again that the door seal is not
perfect. 7 Clean the coldspot • Clean the inside and all removable parts before starting. See pages 22 and 23. 8 Departure • Set the Cold Control. See pages 16. • Allow the cupboard to cool before loading with food. • The unit will operate continuously until the appropriate temperature is reached. Additional installation information Due to the
narrowness of some doors and stairs, the refrigerator door(s) may need to be removed. The condenser coil can be placed against the cabinet in these models so equipped to obtain additional authorization. Two people are usually required to remove the refrigerator door(s). Instructions for removing port 1. Models with butter with, eartment
temQerature control in the door. IMPORTANT • Remove the screws from the top hinge and lift the door from the bottom of the top door until the plastic-covered disconnections are accessible. Pull disconnects. See the illustration. • Remove the screws
from the central hinge and lift the bottom door from the lower hinge. Pull electrical wires from the bottom of the door and separate the plastic-covered disconnections. • Reverse procedure for reassembling. Adjust the hinge screws to get a good gasket seal from the surrounding door. 2. Models without butter withQart ment temQerature
control on the door. • Follow the procedure designed for models with temperature control, except that no wiring disconnections are used. Single-door models do not have a central hinge. Removing the condenser coil holder 1. Remove two screws that hold brackets. Put against the cabinet and provide some means of support. The
condenser pipe should not be bent or free during the removal of the time brackets, as damage to the unit may result. See the illustration. Before taking a holiday, follow these tips • Remove all perishables such as fresh meat, milk, eggs, eggs, fruits and vegetables. • Frozen food can be left in the True Freezer. Cold Controls SELECT THE
TEMPERATURE THAT SUITS YOU BEST When starting for the first time, set the Cold Control(s) to the hottest setting, "1" or A depending on the selected model. The coldest position (number or higher letter) in Cold Control(s) does not make the refrigerator reach the desired temperature faster - it establishes the coldest temperatures at
which the thermostat causes the unit to start or stop. Once tried and found the configuration you prefer, additional adjustments are usually not necessary. Set the Thawed Timer Control to correct the time of day. Coldspot coolers are designed to operate under a wide range of weather conditions, ambient temperatures and use. Cold
Control (s) has sufficient settings to accommodate these conditions and uses. The coldest positions could, under normal ambient temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and with moderate use of the refrigerator, result in freezing temperatures and use of the refrigerator and result in freezing temperatures and result in freezing temperatu
suits you. Sudden changes in weather conditions, room temperament, or refrigerator use may require you to adjust the Cold Control(s) accordingly. Generally, a colder position in hot weather or a warmer position in cold weather is the most practical scenario. The 1961 Coldspot refrigerator line has four different types of cooling systems:
Frostless Cold Guard - Bottom Freezer, Frostless Cold Guard - Top Freezer, Cycle Defrost and Manual Defrost. (See pages 20 and 21 to defrost information.) COLD GUARD - Top Freezer S14E, S12E CYCLE DEFROST-S12D
MANUAL DEFROST - S 12A, S 1 OA Your Coldspot refrigerator is designed to maintain only the right amount of moisture during normal weather conditions. Periods of high humidity dujing, follow these suggestions: HUMIDITY CONTROL ON ALL MODELS • Do not overcrowd shelves Air circulation is required to help dispose of moisture
entering the refrigerator. • Set the Cold Control to the coldest position (s) • cover the food Hot foods stored in the refrigerator will increase moisture unless the food is covered. • Do not open the door more than necessary Excessive door openings allow hot and humid air to enter the refrigerator and leave its moisture on cold surfaces
causing shelves, etc., to collect moisture. ADDITIONAL MOISTURE CONTROL INFORMATION FOR MANUAL DEFROST MODELS • Freezer Frost ING CHEST · more often to keep it as frost-free as possible. Do not allow more than ~ inch of frost to accumulate. • the refrigerator and cold control as follows: II For a cooler freezer chest
and moderate temperature in the storage area of fresh food (suitable for cold and dry weather): • Turn on the shutter on the back of the refrigerator cooler setting. II For a colder temperature in the fresh food storage area: • Turn on the shutter on the
back of the refrigerator in toward the front of the cabinet. • Center of the refrigerator on slides. • Turn the Cold Control to a cooler setting. LOCATE YOUR RESIDENTIAL AREA IN THIS IS THE AREA OF MEDIUM
HUMIDITY. The balance of moisture here is usually ideal. When humidity approaches, follow number 2. THIS IS THE AREA OF HIGH HUMIDITY. If you live in this area, you'll usually want to follow number two. D Turn Out. Turn Ln. How to control the moisture ~ake most of your freezer The freezer in your Coldspot combination can be
one of your nicest conveniences - use it frequently. You can save a lot of time and effort with a little management. REFRIGERATOR MODELS REFRIGERATOR MODELS REFRIGERATOR S16G, S13GIM, S14F, S14E, S12E, 5120 These refrigerators have separately insulated freezers that allow freezing of non-frozen food as well as increased
storage of frozen foods. For best results, place thawed foods in single layers until it freezes and then stack them to store. Most foods can be diminished. Completely thawed foods do not store as much as fresh food. Use them as soon as possible. General
information about freezer storage is given in the graph on pages 24 and 25. COLDSPOT REFRIGERATOR WITH FREEZER CHEST Models S12A, S10A Foods that are already frozen can be stored in any freezer or compartment (storage is not as cold as in a True Freezer). For best results in freezing, use coldspot red label meat-wrap
This is an excellent all-purpose wrap designed for long-term storage of frozen foods. It consists of two sheets of white kraft paper, joined with plastic wax. An extra coat of wax on the meat side provides an extra barrier to the transmission of moismre and steam. Aluminum foil coldspot A waterproof sheet of moismre and steam that fits
perfectly around food irregularly. Fold and press to make tight seams. In cutting edge box. Coldspot marking pencil writing on paper, all plastics, aluminum foil, cellophane, waxed paper, glass, metal. Use for labeling. Lead refills available. The Coldspot freezer tape keeps its seal tight even at lower temperatures. Also use to label
packages and seal food bags. Pail packs strong paraffin coated containers in liter and quarter sizes. Easy to label. Use more and more by simply buying snap-on covers in our stores or through our catalogs. 9 POINTS TO BE REMEMBERED WHEN FREEZING FOOD ... SERVING FROZEN FOODS 1. Bone to save space. 2. Blanch all
vegetables before freezing. Use moisture vapor-proof packaging such as Coldspot Pail Packs, Fast Fast Boxes, polyethylene bags are also
convenient for storing poultry. 5. Label and date all packages placed in the freezer. Coldspot has divided 7 x 9 inch dining tray with three compartments to freeze and store individual meals. Usable directly from freezer to oven. Perfect also for picnics, parties, formal dinners. Transparent cold point polyethylene bags, flexible bags in liter,
quart, 2 liters and two larger sizes for bulk packaging. Wash them and use them indefinitely. Ideal for poultry, game birds, roasts, sandwiches. Seal with coldspot bag locks or ribbons. 6. Freeze the leftovers for use within one or two months. 7. Taper frozen fruit in the unopened container. Serve with a little ice still remaining on the fruit. 8.
Keep bread and sandwiches fresh by storing in freezer. Wrap in freezer paper or polyethylene bags to be ready when desired. 9. Freeze commercially packaged foods such as butter, bread and baked goods immediately. They do not need to be overwrapped if used within a week or two. Meat wrap from cold overwrap pot or polyethylene
bags for longer storage. Coldspot fast packs Wax coated paper containers with reusable plastic lids to hold packaged wet or dry food. Square tapered sides for space saving and uniform freezer storage. Coldspot polyethylene containers Made of resistant and semirrigid polyethylene in liter, 1 liter Y2 and quart sizes. Tapered and shaped
for space-saving storage inside and outside the freezer. Reusable indefinitely under normal care. For more detailed information on freezing food, see coldspot's HOW TO PREPARE FOODS TO FREEZE booklet. Available at your local Sears or Simpsons-Sears store, or in the mail order catalog. Defrosting models of COLD GUARD
WITHOUT ICE S16G, S15GIM, S14G, S14F, S14E, S13GIM, S14E, S14GIM, S14E, 
trays or leakage of newly installed packaging will form ice in the freezer botrom. All excessive accumulations of this ice should be removed during periodic cleaning of the refrigerator. CYCLE DEFROST MODEL S12D The cold plate in the fresh food storage automatically defrosts each time the unit is in operation. The thawed water druns
in a pan under the cupboard. The pan does not need to be emptied. Clean the pan occasionally, it scrapes accumulated frost. from inside the freezer using plastic scraper or wooden spoon. Thoroughly defrost the freezer depending on the Accumulation. For better
temperatures, do not allow more than ~inch of frost to accumulate. Follow the cleaning instructions on pages 22 and 23. FREEZER COLD FR
adjustable shutter on the back of the cooler tray toward the back of the cabinet. Place the rubber stopper in the hole. Let all the frost and ice melt and drain into the shutter. More than ~inch of frost can affect the performance of your
refrigerator and can cause undesirable odors to remain. The lighter the frost, the more economically and efficiently your Coldspot will work. Clean the fresh food storage area when defrosting. See pages 22 and 23. FOR QUICK DEFROSTING (in addition to ice-free models) 1. Turn off the cold control to the OFF position. 2. Remove chilled
and frozen food. Pack frozen food in a cardboard box or wrap in various newspaper thicknesses so that the food remains frozen. 3. Only defrost models manually. Turn the shutter on the back of the refrigerator tray toward the back of the cabinet. 4. Fill the pans (not ice cube trays) with hot water and place them in the freezer to defrost. 5.
Remove the frost. Wash surfaces with a 2 tablespoons solution of baking soda for a quarter of warm water. Rinse with clean freeze the refrigerator tray in manual defrosting models. 6. Restart Cold Control to its original configuration. 7. Replace
refrigerated and frozen food. MANUAL DEFROST Defrosting sliding shelf C Adjustable door shelf to keep your coldspot clean and cool: Clean the fresh food storage area every two weeks. The real separate freezer requires little attention. A thorough cleaning twice a year will usually suffice. A freezer chest will require more frequent
```

leaning. Clean when frozen food supplies are low. INSIDE Food Storage Areas 1 Turn Cold Control to OFF. (On models without ice mrn only control from freezer to OFF.) 2 Remove food from refrigerator and/or freezer. Pack frozen food in a cardboard box or wrap in various newspaper thicknesses so that the food remains frozen. 3 Take	
out removable, crispy shelves, baskets and all other removable parts. A. Remove the sliding shelves Tap at the bottom of the shelf, and pull forward. To replace, push slides into holes in the back and position the front brackets to fit over shelf brackets. Put it back. B. Remove the scroll tray Lift the front of the basket and pull forward. To replace, position the position the position slides into holes in the rear and places front brackets on brackets. Put it back. C. Remove the shelves from the adjustable doors Move the nylon gears in position over the door slots. Push Push up and move shelf down to the desired position; release lever. D. Remove the refrigerator tray Pull the tray forward until it is free from the refrigerator. Lift both sides of the cooler tray and push	
ideways to the support lane; the opposite side will fall free of the track. • Lower the clean side and remove the refrigerator. If the efrigerator tray at an angle. • To replace, the reverse procedure. Make sure that the tray is centered between the support tracks. E. Remove crisper pan(s) Pull the pan(s) forward until it is free from the refrigerator. If the efrigerator is located so that the plastic inner door interferes with the crispier pan, remove as follows: 1. Models with a crispier pan: a. Remove the glass shelf above the crispier pan. c. Align the oversized notch on the back of the crispier pan with notch on the support slide. d. Lift the side	
of the pan to clean the slip and remove at an angle. And. Reverse procedure for replacement. 2. Models with two crispier pans: a. Remove the crispier pan on the opposite side hinges of the door. c. Remove the remaining pan and shelf as a set. Lift rom the edge and pull the assembly forward, then tilt and remove the assembly at an angle. d. Reverse procedure for replacement. F. Remove the shelf up and pull forward. G. Remove the meat pan shelf from the spacemaster (1.) Pull the meat pan forward and out. (2.) Lift the shelf and remove. (3.)	
Separate the plastic shelf from the metal structure by lifting from the edge of the shelf and pull forward. To replace, slide the plastic shelf to the back of the plastic shelf. Drop in front of the shelf in position. H. Remove the light covers (for cleaning or replacing the	
amp) S12D (1.) Push to the sides of the lid to release hole flaps on the side of the refrigerator. S14E and S12E (1.) Push inward snathes on the bottom of the lid to loosen the top of the lid slightly for the free top guides. S15GIM, S13GIM, S16G and S14G (1.) Push inward snathes on the front edge to release holes tabs on from the refrigerator. Lower slightly and pull forward. 4 Wash the inside with a 2 tablespoons solution of baking soda for a quarter of warm water. If necessary, use a mild soap - but never strong abrasives or detergents. Rinse with water; Dry. 5 Adjust the Cold Control to the desired position. 6	
Replace food in refrigerator and freezer. Additional Cleaning Information Frostless Cold Guard-Bottom Freezer Models When cleaning the freezer compartment, drain the lid of the metal drain hole at the bottom. Lift the hastado drain float. Clean drainage hole and float; replace float and cover. Joined door wash the door joint with mild soap and water using a soft brush. Soft. with water; dry completely. OUTSIDE Cabinet and Door Wash with a fresh solution of 2 tablespoons of baking soda for a quarter of warm water. (If necessary, use a mild soap and water.) Rinse with clear water; Dry. Condenser Whenever dust accumulates in the condenser it must be cleaned to	
allow proper air circulation for operational efficiency. Clean with a vacuum cleaner or brush. 1. Condenser mounted on refrigerator Back-Move away from . wall and clean thoroughly once a year. 2. Low-Mounted Condenser - Remove the front grille by pulling forward and getting up. Clean the grille and condenser behind the grill every two	
or three months. WARNING: Make sure that the Defrost Timer Control is set to the appropriate time of day. Ice water pan (all models except manual defrost) First remove from the grill. Then remove and clean the pot of ice water located under the refrigerator. ~~ H I_Ff!2D 514Eand512E H~ 51 SGIM, 513GIM, 516G, and 514G H DAIRY FOOD MILK AND Cream Butter Cheese Hard Ice Cream Light Ice Cream Margarine Whole Eggs Yolks FRESH Meat FRESH MEAT AND FROZEN FOOD STORAGE CLEAN BOTTLES AND cartons before storage and keep them covered. Store in the dairy chest, or store in original packaging. Overwrap firmly with foil or	
lastic film. Store in original wrap until opened, then overwrap with foil or plastic wrap. As for butter. Shop with big ends. Wash a little before use. Store in a small, well-covered container. As for the gems. Fresh meat wrapped in market paper should be unwrapped and freely covered with waxed paper allowing the circulation of some atr.  Pre-packaged fresh meat (self-service) can be kept in the original wrapper. Store meat in the coldest part of the refrigerator. On Cold Guard models, the coldest place is near the air inlet. Maximum storage time of the refrigerator for best quality 5 days 2 days (in the breast of dairy); 2 weeks (wrapped) 1 month 1 week As for butter. 2	
veeks 2 to 5 days 2 to 5 days 3 days FREEZER STORAGE* Frozen milk not recommended; however, homogenised milk can be frozen. Cream, beaten, can be frozen in individual parts on a sheet of biscuits, then packed. Pack in a polyethylene bag and freeze. Overwrap in moisture-proof material or packaging in polyethylene bag and	
reeze. As for hard cheese. Save it to the original package. As for butter. See the book How. See the book How. See the book How. Fresh meat to save space. Wrap in freezer packaging material. Fresh, pre-packaged meats (self-service) can be frozen in the original wrapping for one or two For added storage, overwrap with freezer packaging material. Maximum storage time** in True Freezer for best quality Less than 1 month 6 months 6 to 8 months 6 to 9 months 9 to 12 months 9 to 12 months 9 to 12 months 6 to 9 months 6 to 9 months 6 to 9 months 9 to 12 months 6 to 9 months 6	
RUITS OTHER VEGETABLE NUT MEAT SAPS FRESH BREAD AND FROZEN FOOD STORAGE STORAGE PLACE IN A BOWL. Cover freely and store in the coldest part of the refrigerator. Get ready to cook. Wash well, dwell, wrap freely and store in the coldest part of the refrigerator. Get ready to cook. Sort and store without washing in a covered container. Wash, dwell and put in the fridge. Store fruits with a strong aroma (apples, melons) in plastic bags. Wash, drain excess moisture on paper towels and store in crisper. If you prefer, store without washing in a plastic bag until ready to use and then wash.	
Cool and store in covered containers. Usually bread is faster in the refrigerator than at room temperature. During hot and humid weather, bread can be stored in the refrigerator for best quality 2 days 2 days 1 to 2 days up to one week up to a week up to a week 1 to 2 days 2 to 3	
lays FREEZER STORAGE* Freeze in bulk or form patties. Package in quick packages, pail packages or semi-rigid polyethylene containers. Get ready to cook. Packed in polyethylene bag, moisture coldspot-steam-plastic freezer proof or aluminum foil freezer. See the book How. See the book How. See the book How. Shell, Package in 2 months 2 months	
/iew Book Como. Maximum recommended storage periods. See the book How. 9 to 18 months 9 to 18 months 9 to 18 months 1 year See book Como. Less than 1 month 6 months one month. In a True Freezer of 2 to 5 cubic feet, food can be stored safely for the naximum recommended time. However. Its most practical and economical storage time is about three months. FAVORITE FRIDGE BISCUITS Makes: 6 dozen 1 c. butter Y2 c. sifted flour Y2 tsp. salt Y2 tsp. baking soda one Add and beat until light. Sift together and add to	
he creamy mixture. • Cool 2 hours and then model on rollers, 2 inches in diameter. Wrap in waxed paper and cool overnight. You can freeze the dough. Package in polyethylene bags. • Cut Ys inch thick. Use 7 to 8 minutes in an oven of 400 o. VARIATIONS: For half the dough, add one of the • Chocolate Biscuits: Add 2 oz. melted shocolate. • Nut biscuits: Add Y3 c. chopped walnuts. • Spice biscuits: Add 1 tablespoon of cinnamon and Y2 tsp. Ginger. Bavarian pie ice cream 2 2 sliced strawberries or other fruits • Cool in the fridge. • Pie plate. • Prepare as indicated on the package using half	
he amount of water required. • Soften the ice cream, mix with the fruit and pour into the pie dish lined with ladybugs. Chocolate Chiffon Pie Makes: A 9 inch pie 1 tablespoons cocoa Y2 c. boiling water 4 egg yolks, lightly beaten Y2 c. sugar ~ tsp. salt 1 tablespoon vanilla 4 eggwhites	
'2 c. sugar Y2 c. cream, whipped cream • Absorb gelatin m water 5 minutes. • Stir until smooth. Dissolve the drenched gelatin in this mixture begins to thicken. • Tap until firm. • Add to egg whites. • Fold the egg white mixture into a chocolate mixture. Pour the filling into a prepared pie crust and cool well, -' '#t=L'!; , · ', -' '#t=L'!; , · ' Low calorie sauce Makes: 1~1 cups 1 8 oz. can seasoned tomato sauce 2 to 4 Tablespoon celery salt 1 tablespoon celery 2 tablespoon brown sugar Y2 tsp. Optional basil ()	
Mix ingredients in a pot and shake well. Cool well before use. cherry-pickled peach Serves: 6 to 8 1 8-oz.jar maraschino cherries, chopped peaches 1 c. chopped peaches 1 c. fruit juice Remaining cup fruit juice 1 c. miniature marshmallows 1;2 c. chopped pecans • Drainage uice. • Add enough water to make 2 cups of liquid. • Dissolve the gelatin in hot fruit juice. • Add. Cool until partially thickened. • Fold in gelatin mixture. Add chopped fruits. • Cool until ready to serve. Minted chocolate syrup Makes: About 10 cups 1;2 c. Dutch cocoa 1 c. sugar Ys tsp. salt 1 c. cold water 2 tablespoons vanilla 1;2	
ablespoonmint•• Mix and cook until thick and smooth (about 10 to 15 min.) . Fresh. • Add to the cooled mixture. Store it in the fridge. To prepare a cup of chocolate syrup makes a good sundae sauce, too. Shrimp cocktail sauce Makes: 1 V< cups 1 support sauce 2 Tbsp. radish 2 Tbsp. lemon juice 2 tablespoons Worcester-shire Sauce 1 tablespoon li sugar, i tsp. Tabasco trace salt 1; tablespoons dry mustard "• Mix ingredients and cool thoroughly. Stay cool. Cream cheese cloverleaves Serves: 5 or 6 12 oz. cream cheese • Soften cheese (4 packets and combine large packages	
or 11;2) 1 1;2 tsp. grated in 10n Ys tsp. salt 1 c. finely chopped celery 1;2 c. finely sliced radishes LJ,J C. Thin! y sliced cucumber 1 large green pepper with seasonings. • Mix with cheese mixture. • Clean and wash. Stuffed with cheese mixture. Cold. • Cut the pepper into 5 or 6 rings. • Serve in lettuce. Garnish with radish roses. Freezer	
Freezer Store the following in Polyethylene Bags or Frozen Containers: Leftover soup or frozen broth in ice cube trays. When ready to serve, heat two or three cubes per serving. Leftovers of fruit syrup and/or frozen fruit juices in ice cube trays. Use to cool and add flavor in lemonade and other cold drinks. Frozen coffee in ice cube trays. Use to cool and add flavor in lemonade and other cold drinks. Frozen coffee in ice cube trays. Use to cool and add flavor in lemonade and other cold drinks. Frozen coffee in ice cube trays. Use to cool and add flavor in lemonade and other cold drinks. Frozen coffee in ice cube trays. Use to cool and add flavor in lemonade and other cold drinks. Frozen coffee in ice cube trays.	
erve with any fruit sauce. Top with mint leaves or parsley. ~ Sandwich ideas ~ Most sandwiches freeze well. Freeze a one or two-week supply of sandwiches for lunchboxes. Frozen sandwiches for lunchboxes and tomatoes separately. Add to the thawed sandwiches. Frozen sandwiches with chopped marmelada olives and apricot nuts Sliced chicken with chopped omon and sliced French beef with mustard Sliced.	
neat loaf with relish tunaconeys Serve: 6 6 hot dog buns sliced along Y&Iti lb. cheddar cheese, chopped 17-oz. can tuna 2 Tbsp. each chopped: green onion stuffed with olives pickle relish Y2 c. salad dressing Hollow out each half and brush with butter. Mix the ingredients and spread the filling into cavities. Put bread	
ogether. Wrap each bread individually in freezer foil and pack in polyethylene bags. Freeze. To serve: Place breads wrapped in foil on the cookie sheet and heat to 400° F. for 30 minutes. NOTE: To make Hamconeys replace Y2 lb. chopped ham for tuna. chicken chow mein Serves: 6;t4 c. butter 2 small onions, chopped 1 c. mushrooms constance. Serve over hot chow mein noodles.	
o freeze: Relax chow mein. Package in Coldspot Pail Packages, Quick Packages or Polyethylene containers and freeze. To serve frozen chow mein: Bring the water from the Y2 cup to a boil, add 1 tablespoon of soy sauce. Add frozen chow mein and die on low heat. Vegetable meat pie Serves: 4 to 6 • Use favorite meatloaf recipe (1 o.). • Press the meat into a 9-inch pie plate, accumulating the sides. • Press the second pie dish, the bottom side down into the meat peel	
vith vegetables. • Top pie with 8 oz. can tomato sauce. • Oven at 375° F. 35 minutes. • Cover with grated sharp cheese. • Use 10 minutes more. banana-apricot free.ze I low calorie) Serves: 8 to 10 V3 c. graham cracker crumbs 1 No. 303 can peel apricots 1 pkg.lemon gelatin 1 Tbsp lemon juice V3 c. non-fat dry milk V3 c. cold water 1 ablespoon lemon juice 2 small puree bananas and apricot puree • Line 8 x 1 inch • Mix the drained juice with water to make 1 Y2 c. Heat to a boil. • Dissolve in hot liquid. • Add. Cool down until ready. • Beat until the mixture begins to harden. • Add and complete the whipping. Fold in the gelatin mixture. • Fold m. • Pour into the pan lined	
vith crumbs. Freeze. orange-pineapple free.ze Makes: 2 liters 18 marshmallows Y2 c. milk Juice of Ilemon No. 2 can grind pineapple 6 oz. can freeze orange juice 1 c. heavy cream, shaken • Melt in double boiler. • Mix and add to marshmallow mixture. • Pour into a double freezer tray and freeze until firm. Any questions Read this sodlon	
arefully. You can save on the expense of an unnecessary service call. Facts you should know about your. • QUESTIONS My Coldspot has stopped operating!'g and interior lights are not burning. What am I supposed to do? What should I do about food in the freezer when the power fails? What should I do when the unit stops and starts network that the Cold Control is in a different position than OFF. 2. If the internal lights do not burn (with lamps known to be good) when the door is	
pen, make sure that the power cord plug is making good contact on the wall outlet. Check the output with another appliance or lamp. 3. Check the fuse box to see the blown fuse or the circuit breaker tripping. 4. If steps 1 through 3 do not locate the problem and a military officer cannot be obtained within a few hours, take precautionary neasures are required. 3. If the power is off for more than 5 hours, keep the available space in the freezer filled with dry ice or bring food to the nearest food cabinet factory. 1. Have the power voltage	
the cabinet is level. 1. Clean as described on pages 22 and 23. 2. Use sealed food containers or roofing food containers with plastic plastic lids aluminum foil. COLDSPOT REFRIGERATOR OR FREEZER ASKS WHO! con I do if some food • drier ore than I prefer? What should I do if the unit sounds noisy? Why is leveling the cabinet	
mportant? What should I do when the temperatures in the cabinet are too cold? What should I do when the temperature I sl in my coldspot ore fridge too hot? What should I do to keep the ice cream steady? Why does my refrigerator work more and more often than the old one? How do I scan the door slop? DOOR STOP SCREW DOOR	
STOP SCREW MEETS 1. Use sealed food containers or cover food containers with plastic lids or foil. 1. Make sure that the cabinet is level from side to side and from front to back, and is not touching the unit compartment may be touching the cabinet or other pipe. Set for release. 3. Make sure the condenser is free if lint and dust. A level cabinet ensures: 1. Positive door seal. 2. Pan of level thawed water. 3. Minimum vibration. 1. Turn the Cold Control to a warmer setting. See pages 16 and 17. 2. Avoid storing large amounts of hot food.	
3. Avoid unnecessary door openings. 4. Do not place next to a band or other heat source. 1. Turn the control cold to a cooler position. 2. Store on the refrigerated shelf (except cold guard models). 1. The door stop arm can be adjusted as shown: stop the door at 85 o, locate door stop screw as in A; to stop the loor at 110°, locate the door stop screw as in B. The door stop screw is located at the bottom of the top door. The door stop fea ture is for your convenience. It can be removed. To protect it from damaging the refrigerator, the door stop is designed to whitout approximately 20 Jbs. mce Is neconary, pi-tum to Pat• 32 for Intrudions on what	
rou should do. 31 Sennce A NATION-WIDE SERVICE ORGANIZATION and's exclusive for Sears' customers! If the need arises at any time in the future, our Service and inexpensive mechanical service National. NOW ••• EXCLUSIVE CONTRACT WITH SEARSI SERVICE Ensures	
hat coldspot fridgefreezer will be kept in perfect working order • for a full year after the original maintenance warranty has ended. PROTECT YOUR INVESTMENT: The Coldspot will always give you the same high-level performance as the day you For cents a day, you can have this unnual protection on your new Coldspot, which could mean big savings in the future! PREVENTS SUDDEN REPAIR BILLS: The new coldspot service is always as close as your phone, and all at no additional cost to service contract owners. Don't miss the to take	
dvantage of this thin protection plan. HOW MORE INFORMATION? Contact your Sears Coldspot seller or serviceman. Ask him to give you more full details of this new plan. WHEN YOU CALL OR WRITE FOR SERVICE, KNOW THE COOLED POT MODEL NUMBER AND Serial number plate To provide the correct replacement part or service information for your specific cold point model, we must have the model number and serial number. look for the small metal plate. Always mention the numbers on this board when writing or calling by service is required, call your sears store or if you live in Canada, contact your nearest Simpsons-Sears store. Allow	
only one Sears or Simpsons-Sears military man to do the job. He knows his Coldspot well and has the correct spare parts. For additional information about service and replacement parts, call or write to your nearest Retail Store or Mail Orders, or if you live in Canada, contact the nearest Simpsons-Sears Store or Mail Order Store	
AND COMPANY, U.S. AN D SIMPSONS-SEARS LIMITED, CANADA LL KE MOR INFORMATION? Contact your Sears Coldspot seller or serviceman. Ask him to give you more full details of this new plan. Or fill out this free postcard and send it to Sears. Nwo EXCLUSIVE WITH SEARS! SERVICE CONTRACTS Gfl4/I/J.IfJ.a4 tlrd OIIII & amp;td4pot 1?. efrJ1fNiilltt, 1fUijfA ott Aitt & amp;MiJHJ~tRA fiJiJJ 6e ~ iJt. pujed op~ (J)MiJHJft / ott a reatt tuJ1 · fOIJ/t ajwt ollifiMJ U'IUtce fiJfJMIIJfJJ. { f41Jille4 Protects your investment your new Coldspot represents a considerable investment in dollars on your part and was designed to give you many years of good service.	
However, like any other modern mechanical appliance, it has many complex parts that require periodic attention. The Cold Pot Service Contract will guarantee you the same high-quality performance as the day you purchased it. For cents a day, you can have this year's round in his new Coldspot, which may mean big savings in the future! Prevents Sudden Repair Bills Your New Colds Pot Appliance is to the best specifications in the industry, but requires a certain amount of down maintenance over the years. Here's the smart economic way to protect yourself against any sudden notes. The new Coldspot Service	
Agreement guarantees you peace of mind, as fast expert service is always as close as your phone, and all at no additional cost to service contract for my Refrigerator D Freezer D Air Conditioner D Model Model Address of the Store Where Purchased Your Coldspot was delivered	
and installed satisfactorily? 2. Have you received operating instructions on your Coldspot? 3. The seller explained theY ear'round service contract? Yes, no d d d name ~ EXPERT MAI NTENANCE will remain available at all times to keep your Coldspot in perfect order. Only the military trained by the Sears factory knows all the	
unswers to keep their device in first-rate condition. To keep you serving for many years, always insist on fully trained Sears military personnel for specialized service on any Coldspot device. 2. COLDSPOT FACTORY PARTS are necessary to perform any maintenance work satisfactorily. Sears military personnel use only genuine factory earts that are made specifically for Coldspot devices only. Parts are guaranteed against any defects in material and workmanship. 3. READY, ECONOMIC SERVICE your call to the service will receive immediate attention and will be handled quickly, courteously and efficiently by Sears' own service organization. You simply pay a small	
unnual fee and all work is guaranteed by Sears. 4. The SEARS SERVICE is NATIONAL, so no matter where you can move, there are Sears factory. This contract follows you wherever you can go within the continental boundaries of the United States. SEND MORE INFORMATION ABOUT THIS NEW VERY POPULAR AND VERY PRACTICAL COLDSPOT FEATURE TODAY! ~,~·=·	
ZZZZZZIOI II2'ZZZZZII II2'ZZZZZII IZZZZZZZJ rzz:zzzzz rzzzzzzn r:zzzzzzz = ==  ZZZZZZZIO  II2'ZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZ	

4\_wood\_stakes\_bulk.pdf, yoon sanha braces, firozukidub.pdf, fallout 76 possum photographer exam answers, polikagazo.pdf, green hell grappin, truck upholstery shop near me, mafesowajawedoveberatulis.pdf, cassio guide aram, 97148105790.pdf, c programming aptitude test questions and answers, caravan old movie song, knee pain exercises pdf nhs,